





SINGER
293B

LIST OF PARTS - MACHINE 293 B




ATTACHMENT SET 161800


8879	Felt Washer
25527	Cloth Guide
50053	Guide Screw
121464	Binder
125453	Bobbin (3)
161127	Zipper Foot
161294	Screwdriver (LG)
161295	Screwdriver (SM)
161801	Tube of Oil
2020(15x1)	Needles 11 (3) 14 (3)
B 173	Instruction Book



BZB 60-8 MOTOR OUTFIT N° 87023-005



S7 LIGHT COMPLETE N° 81295-092



FOOT CONTROLLER COMPLETE 197783-025

